



Pin number	Symbol	Level	I/O	Function
1	Vss	-	-	Power supply (GND)
2	Vcc	-	-	Power supply (+5V)
3	Vee	-	-	Contrast adjust
4	RS	0/1	I	0 = Instruction input 1 = Data input
5	RW	0/1	I	0 = Write to LCD module 1 = Read from LCD module
6	E	1, 1->0	I	Enable signal
7	DB0	0/1	I/O	Data bus line 0 (LSB)
8	DB1	0/1	I/O	Data bus line 1
9	DB2	0/1	I/O	Data bus line 2
10	DB3	0/1	I/O	Data bus line 3
11	DB4	0/1	I/O	Data bus line 4
12	DB5	0/1	I/O	Data bus line 5
13	DB6	0/1	I/O	Data bus line 6
14	DB7	0/1	I/O	Data bus line 7 (MSB)

Title		
CABINHO NO LCD		
Size	Document Number	Rev
A	<Doc>	<RevCode>
Date:	Wednesday, March 26, 2008	Sheet 1 of 1